

To update the firmware of Vortex VX1e insert a Spektrum bind plug to the DPOD port, then power it on. The light on the VX1e will flash rapidly purple to indicate that the firmware loader is active. You may now connect it to your computer using a micro USB cable. Wait for Windows to detect it and load the required drivers, then run the update application.

If a Spektrum bind plug is not available use the supplied receiver wire as shown in this photo. This will create the required connection to activate the firmware loader.

